



- A- Disconnect the 24 volt power cord
- B- Remove collector pad
- C- Cut electrode to remove titanium ball
- D- Unscrew power head cover
- E- Lift power head with cover
- F- Loosen ground wire screw
- G- Remove power head
- H- Insert new power head

- I- Tighten in ground wire
- J- Screw in power head cover
- K- Slip new titanium ball on electrode
- L- Slip the rivet under ball
- M- Squeeze the rivet
- N- Place pad into the panel
- O- Reconnect the 24 volt power cord